



AIRCRAFT MANUFACTURER	MODEL	AIRCRAFT SERIAL NUMBER	YEAR	AIRCRAFT MFR. PART NO.	HEATER PART NO.
BEECHCRAFT TWIN BEECH	D18S	A-38 to A-1019	1946-1954	404-001039-1	8253B (Use 8259L)
BEECHCRAFT	E18S	BA-1 to BA-272	1955		F93A22
BEECHCRAFT	E18S G18S G18	BA-273 and after	1955-1966		G93A22
BEECHCRAFT TWIN BONANZA	B50 C50 D50 D50A D50B D50C E50 F50 G50 H50	CH-12 to CH-110 CH-111 to CH-360 DH-1 to DH-154 DH-155 to DH-198 DH-199 to DH-236 DH-237 to DH-262 EH-1 to EH-70 FH-71 to FH-96 GH-97 to GH-119 HH-120 to HH-134		50-555015-2	C83A28
BEECHCRAFT TWIN BONANZA	D50C H50 J50	DH-263 and after HH-135 and after JH-150 to JH-176		50-555015-8	E83A28
BEECHCRAFT BARON	55, A55 B55, B55A C55, C55A D55, D55A E55	TC-1 to TC-1607 TE-1 to TE-942 Except TE-938	1961-1974	95-554024	D83A28
BEECHCRAFT BARON	B55 E55 58	TC-1608 to TC-1657 TE-938, TE-943 to TE-958 TE-960 to TE-967 TH-1 to TH-436	1974-1976	95-554024	D83A28
BEECHCRAFT BARON	B55 E55 58	TC-1658 to TC-1875 TE-959, TE-968 to TE-1048 TH-437 to TH-633	1975-1976	58-380057-3	81D94-1 (Use 81D94-3)
BEECHCRAFT BARON	B55 E55 58	TC-1876 to TC-1926 TC-1927 and after TE-1049 to TE-1075 TE-1076 and after TH-634 to TH-712 TH-713 and after		58-380057-7 58-380057-9	81D94-3
BEECHCRAFT BARON	56TC A56TC	TG-1 to TG-83 TG-84 to TG-94	1967-1971	95-554024-1	F83A28
BEECHCRAFT BARON (PRESS.)	58P	TJ-3 to TJ-228	1976-1979	102-384010-1	82D20-1
BEECHCRAFT BARON (PRESS.)	58P	TJ-229 and after	1979	102-384026-1	07E02-1
BEECHCRAFT BARON	58TC	TK-1 and after	1976-1982	58-380057-7	81D94-3
BEECHCRAFT DUKE	60 A60	P-4 to P-122 P-124 to P-126 P-123 P-127 to P-246	1968-1973	60-384014-1	A34D51 (Use C34D51)
BEECHCRAFT DUKE	B60	P-247 and after	1974-1982	60-384014-3	C34D51

CAUTION: Reference only. Please consult aircraft manufacturers manual for actual application.



AIRCRAFT MANUFACTURER	MODEL	AIRCRAFT SERIAL NUMBER	YEAR	AIRCRAFT MFR. PART NO.	HEATER PART NO.
BEECHCRAFT QUEEN AIR	65 80 A80	LC-1 and after LD-1 to LD-150 LD-151 and after	1960-1966	50-5554201	A80C65
BEECHCRAFT QUEEN AIR	A65 70 B80	LC-240 to LC-335 LB-1 to LB-35 LD-270 to LD-511	1966-1978	50-554201-15	D80C65
BEECHCRAFT DUCHESS	76	ME-1 to ME-182	1978-1979	105-550000-1	07E94-1
BEECHCRAFT DUCHESS	76	ME-183 and after	1979-1982	105-550000-43	07E94-2
BEECHCRAFT QUEEN AIR	88	LP-1 to LP-26, LP-28 LP-30 to LP-47	1966-1967	50-554228-139	C80C65
BEECHCRAFT KINGAIR	90 A90 B90	LJ-1 to LJ-59	1965	50-554228-147	A10D40 (Use C10D40)
BEECHCRAFT KINGAIR	90 A90 B90	LJ-60 to LJ-501	1965-1970	50-554228-137	B10D40 (Use C10D40)
BEECHCRAFT TRAVELAIRE	95 B95 B95A D95A E95	TD-1 to TD-302 TD-203 to TD-452 TD-453 and after		95-554024	D83A28
BEECHCRAFT AIRLINER	99	U-1 to U-164	1968-1974	115-384004-3	E10D40
BELL	OH13	All			15D94
BELL	47G3BIT	All			15D94
BELL	206A	All			37D88
BELL	206B	All			A37D88
BELL	206B	All			B37D88
BELL	OH58A	All			39D90
BELL	206L	All			39D90-1
BRITTEN NORMAN ISLANDER	BN-2	All			11E82-1
BRITTEN NORMAN ISLANDER	BN-2T	All			90E00-1
CANADAIR	CL215	All			99C80
CANADAIR	CL215T CLT-415				91E18-1
CESSNA CRUSADER	T303	All	1982-1984	C166040-0301	19E69-1
CESSNA	310, 310B 310C 310D	35000 to 35024	1955	0813800	978 OBSOLETE (Use 940F-24)
CESSNA	310 310B 310C 310D	35025 to 35546	1955-1957	0813900-2	940B-24

CAUTION: Reference only. Please consult aircraft manufacturers manual for actual application.



AIRCRAFT MANUFACTURER	MODEL	AIRCRAFT SERIAL NUMBER	YEAR	AIRCRAFT MFR. PART NO.	HEATER PART NO.
CESSNA	310 310B 310C 310D	35547 and after	1958-1960	0813825-4	8240A
CESSNA	310F, 310G 310H, 310I 310J, 310K	310-0001 to 310I-0001	1961-1964	0813825-4	8240A
CESSNA	310F, 310G 310H, 310I 310J, 310K	310I-0001 and after	1964-1966	0813841-1	96C62 (Use 96C62-1)
CESSNA	310L 310N	310L-0001 and after 310N-0001 and after	1967-1968	0813841-1	96C62 (Use 96C62-1)
CESSNA	310P T310P 310Q T310Q	310P-0001 to 310Q-0453	1969-1970 1970-1974	0813841-9	96C62-1
CESSNA	310Q T310Q	310Q-0454 and after	1969 1970-1974	0813860-3	8240E
CESSNA	310R	310R-0001 to 310R-0800	1975-1981		8259HR2
CESSNA	310R	310R-0801 and after	1975-1981		8259JR2
CESSNA SKYKNIGHT	320 320C	320-0001 to 320C-0000	1962, 1963 1964	0813825-4	8240A
CESSNA SKYKNIGHT	320C 320D	320C-0001 to 320D-0000	1965	0813841-1	96C62 (Use 96C62-1)
CESSNA SKYKNIGHT	320D 320E 320F	320D-0001 to 320F-0020 320F-0021 and after	1967-1968	0813841-1 0813841-9	96C62 96C62-1
CESSNA	335	335-0001 and after	1980		8259M
CESSNA SKYMASTER	T337 FT337	337-0569 and after F337-00001 and after	1967-1972	C166040-0102 C166040-0101	42D79 (Use FR42D79-1EL)
CESSNA PRESS. SKYMASTER	T337 FT337 T337 FT337 T337 FT337 T337 FT337	P337-0001 to P337-0091 FP337-0001 to FP337-0008 P337-0092 to P337-0213 P337-0215, P337-0217 to P337-0222 FP-0009 to FP337-0013 P337-0226 and after FP337-0016 and after P337-0214, P337-0216 P337-0223 to P337-0225 FP337-0014 to FP337-0015	1973-1980	C166040-0201 C166040-0202 C166040-0203 C166040-0204	74D01 74D01-1 74D01-2 74D01-3
CESSNA	340 340A	340-0001 to 340A-0200	1972-1984	9910088-13	8472D
CESSNA	340A	340A-0201 to 340A-0648	1972-1984	9910305-2	02E17-2
CESSNA	340A	340A-0649 and after	1972-1984	9910305-8	13E55-2
CESSNA	401 401A 401B 402	401/402-0001 to 401/402-0067	1967-1978	5017529-3	8259GL (Use 8259GL1)

CAUTION: Reference only. Please consult aircraft manufacturers manual for actual application.



AIRCRAFT MANUFACTURER	MODEL	AIRCRAFT SERIAL NUMBER	YEAR	AIRCRAFT MFR. PART NO.	HEATER PART NO.
CESSNA	401 401A 401B 402	401-0068 and after 402-0068 to 402A-0001	1967-1978	5017529-4	8259GL1
CESSNA	402A 402B	402A-0001 to 402B-0445	1967-1978	5017530-2	8259GL2
CESSNA	402B	402B-0446 and after	1967-1978	5217530-2	8259HL2
CESSNA	402C	402C-0001 and after	1979-1985	5217530-2	8259HL2
CESSNA	404	404-0001 and after	1977-1981	5217530-2	8259HL2
CESSNA	411 411A	411-0001 to 411-0200	1965-1966	5017529-1	8259DL
CESSNA	411 411A	411-0201 to 411-0250	1966	5017529-2	8259FL (Use 8259FL1)
CESSNA	411 411A	Spare are 411-001 to 411-0250	1965-1966	5017529-5	8259FL1
CESSNA	414	414-0001 to 414-0261	1969-1985	9910004-11	A34D35
CESSNA	414	414-0262 to 414-0900	1969-1985	9910088-15	8472C/E
CESSNA	414	414-0901 to 414A-0000	1969-1985	9910305-1	02E17-1
CHANCELLOR	414A	414A-0001 to 414A-0217			
CESSNA	414A	414A-0218 and after	1969-1985	9910305-7	13E55-1
CESSNA	421 421A 421B	421-0001 to 421B-0228	1968-1975	9910004-11	A34D35
CESSNA	421B	421B-229 and after	1968-1975	9910088-11	8472C/E
CESSNA	421C	C0001 to C0200	1976-1985	9910088-11	8472C/E
CESSNA	421C	C0201 to C0628	1976-1985	9910305-1	02E17-1
CESSNA	421C	C0629 and after	1976-1985	9910305-7	13E55-1
COMMANDER	520	1-150	1952-1954	5880002-13	B03C08
COMMANDER	500A 500B 560F 680F	871 to 1230	1960-1962	5880035-15	C15C54
COMMANDER	500A 500B 500U 560F 680F	1231 and after	1962-1967	5880035-5	C15C54
GULFSTREAM	500S	1755 to 3075	1968-1970	880035-5	C15C54
COMMANDER	500S	3076 and after	1970-1985		62D95-1B
GULFSTREAM	680FL 688FL-P	All	1963-1969	5880035-5	C15C54
COMMANDER	680T 680V 680W 681		1966-1967	5880118-503	A58C26

CAUTION: Reference only. Please consult aircraft manufacturers manual for actual application.



AIRCRAFT MANUFACTURER	MODEL	AIRCRAFT SERIAL NUMBER	YEAR	AIRCRAFT MFR. PART NO.	HEATER PART NO.
COMMANDER	500 560 560A 680 560E 680E 720	618 and after 151 to 230 231 and after 231 and after 434 and after 611 and after 501 and after	1954-1967	5880035-15	C15C54
COMMANDER	685	12000 and after	1972-1974	880329-1	63D98
DE HAVILAND OTTER	DHC3				24E07-1
DORNIER SKYSERVANT		All			99C80
DORNIER SKYSERVANT	DO128-6	All			24E07-1
FUGI	FA300	All			96D75-1
LAKE AMPHIB	LA-4	All			99C42
LAKE AMPHIB					99C92-1
PARTENAVIA	P-68C P-68TC	All			99C80
PIPER APACHE	PA-23	23-1 to 23-170	1954-1955	18591-00	979 (Obsolete) (Use 940B12)
PIPER APACHE	PA-23	23-171 to 23-1242	1955-1958	464 321	940B12
PIPER APACHE	PA-23	23-1243 and after	1958-1960	464 324	940DA12
PIPER AZTEC Carb. Model-12V	PA-23	27-1 to 27-3049 27-3051 to 27-3153	1960-1966	464 324	940DA12
PIPER AZTEC Fuel Inj. Model-12V	PA-23	27-1 to 27-3049 27-3051 to 27-3153	1960-1966	464 338	940DB12
PIPER AZTEC Carb. Model-28V	PA-23	27-1 to 27-3049 27-3051 to 27-3153	1960-1966	464 323	940D24
PIPER AZTEC Carb. Model-28V	PA-23	27-2298, 27-2331	1963	464 341	940DA24
PIPER AZTEC Fuel Inj. Model-12V	PA-23	27-2505 to 27-3153	1960-1966	464 352	940K12 (Use 940DB12)
PIPER AZTEC-12V	PA-23	27-3050, 27-3154 to 27-7405427 27-7405429 to 27-7405476	1965-1974	751 978	37D77 (Use 37D77-1)
PIPER AZTEC-12V	PA-23	27-7405428	1974	755 256	37D77-1
PIPER AZTEC-24V	PA-23	27-3584 to 27-7554038	1966-1975	751 999	45D70 (Use 45D70-2)
PIPER AZTEC-24V	PA-23	27-7554039 to 27-8054059	1975-1980	755 257	45D70-1 (Use 45D70-2)
PIPER AZTEC-24V	PA-23	27-8154001 and after	1980-1981	755 324	45D70-2
PIPER TWIN COMANCHE	PA-30	30-2 to 30-401	1963-1964	464 346	940DC12
PIPER TWIN COMANCHE	PA-30 PA-39	30-402 and after 39-1 and after	1964-1972	751 959	20D35 (Use 20D35-1)
PIPER NAVAJO	PA-31	31-5 to 31-7401248 31-7401250 to 31-7512064	1967-1975	751 986	39D59 (Use D39D59)
PIPER NAVAJO	PA-31	31-7401249, 31-7512065 to 31-7912124	1967-1975	755 273	B39D59 (Use D39D59)
PIPER NAVAJO	PA-31	31-8012001 and after	1980	755 312	D39D59

CAUTION: Reference only. Please consult aircraft manufacturers manual for actual application.



AIRCRAFT MANUFACTURER	MODEL	AIRCRAFT SERIAL NUMBER	YEAR	AIRCRAFT MFR. PART NO.	HEATER PART NO.
PIPER NAVAJO (Aft Heater)	PA-31	31-5 to 31-7712012	1967-1977	752 017	A39D59 (Use C39D59)
PIPER NAVAJO (Aft Heater)	PA-31	31-7712013 and after	1977-1983	755 275	C39D59
PIPER NAVAJO CHIEFTAIN	PA-31-350	31-5001 to 31-7305103	1973	755 234	65D79 (Use 65D79-3)
PIPER NAVAJO CHIEFTAIN	PA-31-350	31-7305104 to 31-7405461 31-7405463 to 31-7552032 31-7552037 to 31-7552038	1973-1975	755 248	65D79-1 (Use 65D79-3)
PIPER NAVAJO CHIEFTAIN	PA-31-350	31-7405462 31-7552033 to 31-7552036 31-7552039 to 31-7952250	1974-1979	755 263	65D79-2 (Use 65D79-3)
PIPER NAVAJO CHIEFTAIN	PA-31-350	31-8052001 and after	1980-1984	755 311	65D79-3
PIPER NAVAJO T1020	PA-31-350 T1020	31-8253001 to 31-8253012 31-8353001 to 31-8353007 31-8453001 and after	1982 1983 1984	755 311	65D79-3
PIPER NAVAJO PRESSURIZED	PA-31P	31P-3 to 31P-7530008 31P-7530010 to 31P-7630006 31P-7630009, 31P-7630010	1970-1976	752 018	47D65 (Use 47D65-3)
PIPER NAVAJO PRESSURIZED	PA-31P	31P-7530009 31P-7630007 31P-7630008 31P-7630011 and after.	1975-1976	755 260	47D65-1 (Use 47D65-3)
PIPER NAVAVO MOJAVE	PA-31P-350	31-8414001 to 31P-8414025	1983-1984	755 348	47D65-3
PIPER CHEYENNE	PA-31T	31T-7400002 to 31T-752017 31T-7520019 to 31T-7620015 31T-7620031 to 31T-7720005	1974-1977	755 244	62D33 (Use 62D33-2)
PIPER CHEYENNE	PA-31T	31T-7520018 31T-7620016 to 31T-7620030 31T-7720006 to 31T-7720069	1975-1977	755 261	62D33-1 (Use 62D33-2)
PIPER CHEYENNE	PA-31T	31T-7820001 to 31T-7820066 31T-7804001 to 31T-7904007	1978-1979	755 283	62D33-2
PIPER CHEYENNE	PA-31T PA-31T1	31T-7820067 to 31T-7920041 31T-7904008 to 31T-7904015	1978-1979	755 286	10E21-1 (Use 10E21-4)

CAUTION: Reference only. Please consult aircraft manufacturers manual for actual application.



AIRCRAFT MANUFACTURER	MODEL	AIRCRAFT SERIAL NUMBER	YEAR	AIRCRAFT MFR. PART NO.	HEATER PART NO.
PIPER CHEYENNE	PA-31T PA-31T1	31T-7920042 to 31T-8020092 31T-8120060 and after. 31T-7904016 to 31T-8004057 31T-8104068 to 31T-8304003 31T-1104004 and after.	1979-1983	755 307	10E21-2 (Use 10E21-4)
PIPER CHEYENNE	PA-31T PA-31T1	31T-8120001 to 31T-8120059 31T-8104001 to 31T-8104067	1981	755 334	10E21-4
PIPER T1040	PA-31T3 T1040	31T-8275004, 31T-8275017 31T-8375003	1982-1983	755 346	23E62-2
PIPER SENECA	PA-34-200	34-7250001 to 34-7450220	1972-1974	78355-05	82D31-1
PIPER SENECA II	PA-34-200T	34-7570001 to 34-7570337	1975	78355-05	82D31-1
PIPER SENECA II	PA-34-200T	34-7670001 to 34-8170092	1976-1981	464 401	90D38-1
PIPER SENECA III 12VDC	PA-34-220T	34-8133001 to 34-8633031 3433001 and after	1981-1986	464 401	90D38-1
PIPER SENECA III 24VDC	PA-34-220T	3448005 and after		689 940	91E88-1
PIPER SENECA IV 24VDC	PA-34-220T	3447001 to 3447012 3447013 to 3447029	1995 1996	689 940	91E88-1
PIPER SENECA V 24VDC	PA-34-220T	3449001 to 3449041 3449042 to 3449096 3449097 and after.	1997 1998 1999	689 940	91E88-1
PIPER SEMINOLE	PA-44-180 PA-44-180T PA-44-180	44-7995001 to 44-7995329 44-8095001 to 44-8095027 44-8195001 to 44-8195026 44-8107001 to 44-8107066 44-8207001 to 44-8207020 4495001 to 4495009 4495010 to 4495012 4495013 4496001 and after.	1979 1980 1981 1981 1982 1989 1990 1993	464 427	90D38-2
PIPER AEROSTAR	600	0001 to 0165	1968-1974	755 327	22D25 (Use 22D25-1)
PIPER AEROSTAR	600	0166 and after.	1974-1981	755 328	22D25-1
PIPER AEROSTAR	601-601P	0001 to 0165.	1969-1974	755 329	B34D51
PIPER AEROSTAR	601 601P 602P PA-60-700P	0166 and after.	1974-1981	755 330	D34D51
PIAGGIO	P166DL3	All			88D81-1 88D81-3
RILEY ROCKET	421	All			88D81-1
VOLPAR	402	All			88D81-1
WING		All			99C42

CAUTION: Reference only. Please consult aircraft manufacturers manual for actual application.